OPERATOR´S CABIN

The opertor's cabin for both Siwertell continuous screw-type ship unloaders and for
Siwertell ship loaders of screw, belt and aeroslide design, is mounted on an arm at
the same level as the horizontal arm of the unloader/loader, the operator's cabin
slews along with the horizontal arm.

SCAN THE QR-CODE:
And view the Page online, where you will have access to more information