

## OPERATOR'S CABIN

The operator's cabin for both Siwertell continuous screw-type ship unloaders and for Siwertell ship loaders of screw, belt and aeroslide design, is mounted on an arm at the same level as the horizontal arm of the unloader/loader, the operator's cabin slews along with the horizontal arm.

**SCAN THE QR-CODE:**  
And view the Page online,  
where you will have access  
to more information

