

OPERATOR'S CABIN

The operator's cabin for both Siwertell continuous screw-type ship unloaders and for Siwertell ship loaders of screw, belt and aeroslide design, is mounted on an arm at the same level as the horizontal arm of the unloader/loader, the operator's cabin slews along with the horizontal arm.

SCAN THE QR-CODE:
And view the Page online,
where you will have access
to more information

