



**SCAN THE QR-CODE:**  
And view the Page online,  
where you will have access  
to more information



## LOADING SYSTEM

### DOUBLE-BELLOW SYSTEM

The up and down movements of the loading bellows are electrically-operated from the ground, via a wireless control box, or from the electrical connection box at the bellows. A level guard sends a stop signal to the unloader, indicating that the receiving equipment, for instance a truck, belt conveyor or rail wagon, cannot receive any more material.



The double-bellows system makes it possible to load at two points alternately using internal slide gates, ensuring that unloading can continue during truck or wagon changeovers. This feature can be automatically-controlled via the PLC or manually from the wireless control box.



### SINGLE-BELLOW SYSTEM

When only a single loading point is required the single bellow or loading chute option is available.

[Back to Road-mobile UNLOADERS](#)