



## SCAN THE QR-CODE:

And view the Page online, where you will have access to more information



## **LOADING SYSTEM**

## **DOUBLE-BELLOW SYSTEM**

The up and down movements of the loading bellows are electrically-operated from the ground, via a wireless control box, or from the electrical connection box at the bellows. A level guard sends a stop signal to the unloader, indicating that the receiving equipment, for instance a truck, belt conveyor or rail wagon, cannot receive any more material.



The double-bellows system makes it possible to load at two points alternately using internal slide gates, ensuring that unloading can continue during truck or wagon changeovers. This feature can be automatically-controlled via the PLC or manually from the wireless control box.



## **SINGLE-BELLOW SYSTEM**

When only a single loading point is required the single bellow or loading chute option is available.



Back to Road-mobilE UNLOADERS